

SIS Purse Pattern and Instructions for 10cm (4") wide Acrylic Jelly Clip

Supplies Needed

10 cm Jelly Clip
Main Fabric – 2 pieces approx 6" x 7"
Lining Fabric – 2 pieces approx 6" x 7"
Fusible Interfacing – 2 pieces approx 6" x 7"
Permanent Fabric/Craft Glue

$\frac{1}{4}$ " Seam Allowance

Assembly Instructions:

- 1 – **Fuse** interfacing to wrong side of main fabric.
- 2 – **Trace** purse pattern. (Front and back use same pattern)
- 3 – **Cut** 2 purses from Main Fabric and 2 from Lining Fabric.
- 4 – **Stitch** darts as marked with right sides together.
- 5 – **Stitch** main fabrics together from **X** to **X** around lower edge, with right sides together, leaving top of purse open.
- 6 – **Stitch** lining fabrics together from **X** to **X** around lower edge with right sides together, leaving top of purse open.
- 7 – **Turn** purse lining right side out.
- 8 – **Insert** lining purse inside main purse, right sides together, matching side seams and top raw edges.
- 9 – **Stitch** around top of purse, right sides together leaving an opening on one side between dots.
- 10 – **Turn** purse right side out through the opening. Tuck lining into main purse and press, folding the opening seam allowance in.
- 11 – **Topstitch** edge around top of purse, this gives you a strong edge to tuck into purse frame, when gluing.
- 12 – **Apply** small bead of glue inside the groove on one side of the Jelly Clip. Let gravity help keep the glue in the frame, by turning the purse upside down.
- 13 – **Insert** purse top edge into groove, gathering as needed in the center to fit purse frame, matching seams to sides of purse. Use an awl or stiletto or other pointed tool to push the fabric firmly all the way into groove.
- 14 – Check inside and outside purse to make sure all edges are inserted securely.
- 15 – **Repeat** steps 12 and 13 for other side of purse.
- 16 – Let dry completely before using, so glue is firmly bonded.

